


Salmon Cut – fully trimmed 98%VL



Position of the silverside.

Code: 1052



1 Silverside with salmon cut and heel muscle.



2 Remove the heel muscle by following the natural seams.



3 Silverside with salmon cut. Remove all visible fat.



4 Silverside and salmon cut fully trimmed, 98%VL.



5 Remove the salmon cut by following the natural seam.



6 Salmon Cut – fully trimmed 98%VL.